

Date et heure dans Node red

Avec le noeud Date/Time Formater

Il faut dans le menu " Gerer la palette" installer ==> **node-red-contrib-moment**



Dans node-red , mettre les noeuds suivant :



Le noeud "Horodatage"

The screenshot shows the configuration interface for a Node-RED inject node. The title is "Modifier le noeud inject". At the top, there are three buttons: "Supprimer", "Annuler", and "Terminer". Below this is a "Propriétés" section with a search bar and three icons. The "Nom" field is empty. There are two message boxes: "msg.payload" with the value "horodatage" and "msg.topic" with the value "2". At the bottom, there is a checkbox "Injecter une fois après 0.1 secondes, puis" which is unchecked. Below that is a "Répéter" section with a dropdown menu set to "intervalle" and a "chaque" field set to "1" with a unit dropdown set to "secondes".

le noeud "Date/Time Formatter" pour la date

Modifier le noeud Date/Time Formatter

Supprimer Annuler Terminer

Propriétés

← Input from horodatage

Input Timezone Europe/Paris

Adjustment + 0 Hours

Output Format DD - MM - YYYY

🇫🇷 Locale fr-FR

Output Timezone Europe/Paris

→ Output to msg. mytime

📄 Topic Topic

🔑 Name Format date

See the info sidebar for formatting details.
Use locale and format to change string output.
See the info sidebar for several warnings about inputting strings.

From: <https://www.magenealogie.chanterie37.fr/www/fablab37110/> - Castel'Lab le Fablab MJC de Château-Renault

Permanent link: <https://www.magenealogie.chanterie37.fr/www/fablab37110/doku.php?id=start:esp32:nodered:heure:nr&rev=1706004537>

Last update: 2024/01/23 11:08

